

## 8-Port Rackmount KVM Switch - 4K 60Hz



*Actual product may vary from photos*

### User Manual

**SKU#: R8AD122-KVM-SWITCH / R8AD122-KVM-SWITCH**

For the latest information and specifications visit:  
[www.startech.com/r8ad122-kvm-switch](http://www.startech.com/r8ad122-kvm-switch) or [www.startech.com/r8ah202-kvm-switch](http://www.startech.com/r8ah202-kvm-switch)

## **Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols**

This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of third-party companies not related in any way to StarTech.com. Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by StarTech.com, or an endorsement of the product(s) to which this manual applies by the third-party company in question. Regardless of any direct acknowledgement elsewhere in the body of this document, StarTech.com hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders.


PHILLIPS® is a registered trademark of Phillips Screw Company in the United States or other countries.

# Table of Contents

<b>Product Diagram .....</b>	<b>3</b>
Front View .....	3
Rear View .....	4
<b>Installation .....</b>	<b>5</b>
(Optional) Rack Mount the KVM Switch.....	5
Connect the Console .....	7
Connect the PCs .....	7
<b>Hotkey Commands.....</b>	<b>8</b>
Hotkey Leading Code .....	8


# Product Diagram

## Front View



	Component	Function
1	USB Hub Ports	<ul style="list-style-type: none"> <li>Connect <b>USB Peripheral Devices</b> such as a <b>Mouse</b>, <b>Keyboard</b>, or <b>USB Flash Drive</b></li> <li>Supports <b>USB 480Mbps</b></li> </ul>
2	PC 1- 8 Selection Buttons with LEDs	<ul style="list-style-type: none"> <li>Press the <b>Button</b> to switch to the corresponding port</li> <li>LED Lights:               <ul style="list-style-type: none"> <li><b>Solid Green:</b> Port Selected</li> <li><b>Blinking Green:</b> Port Selected but no Video input detected</li> </ul> </li> </ul>

## Rear View



Component		Function
1	DisplayPort Output Port	• Connect to a <b>DisplayPort Monitor</b>
2	PC 1 - 8 DisplayPort Input	• Connect to a <b>DisplayPort Source Device</b>
3	DC Power Input	• Connect the included <b>Universal Power Adapter</b> to the <b>KVM Switch</b>
4	USB HID Ports	• Connect a <b>Human Interface Device (HID)</b> (e.g. Keyboard, Mouse, Trackpad, Number Keypad, or Drawing Tablet)
5	3.5mm Audio Output	• <b>Green:</b> Connect to a <b>3.5mm Audio Source Device</b>
6	8x PC USB Host Connection	• Connect to a <b>Computer</b> with a <b>USB Port</b>
7	8x PC Audio Input	• Connect to a <b>3.5mm Audio Port</b> on <b>PC 1 - 8</b>

# Installation

## (Optional) Rack Mount the KVM Switch

1. Place the **Mounting Brackets** on each side of the **KVM Switch**. Align the **Holes** in the **Mounting Brackets** with the **Holes** on the sides of the each side of the **KVM Switch**.
2. Insert four **Screws** through each **Mounting Bracket** and into the **KVM Switch**.
3. Tighten each **Screw** using a **Phillips Head Screwdriver**.
4. Locate a suitable location, in the **EIA-310 Compliant Rack Space**, to mount the **KVM Switch**.

**Note:** The **KVM Switch** requires 1U of rack-space.




Figure 1

5. If the **EIA-310 Compliant Rack Space** uses square mounting holes, install **Cage Nuts** (not included) into the square mounting holes on the **1U** of **EIA-310 Compliant Rack Space**.

6. Place the **KVM Switch** into the rack-space and align the mounting holes on the **Mounting Brackets** with the mounting points on the rack space (e.g. the cage nuts, if used).
7. Use **Cabinet Screws** (not included) to secure the **KVM Switch** to the rack. If not using cage nuts or M5/M6 threaded rack posts, the appropriate mounting hardware for the rack should be used.




Figure 2

**Note:** Ensure the screws are properly tightened and the **KVM Switch** has no movement.

8. The **KVM Switch** is now installed into the 19-inch **EIA-310 Compliant Rack Space**.

## Connect the Console

**Note:** *Power off all Computers, Displays, and Peripherals before completing the following steps.*

9. Connect the **DisplayPort Display** to the **DisplayPort Output Port**, located on the rear of the **KVM Switch**, using a **DisplayPort Cable** (sold separately).
10. Connect a **USB Mouse** and a **USB Keyboard** to the **Console USB HID Ports**, located on the rear of the **KVM Switch**.
11. (Optional) Connect up to two additional **USB HID Devices** to the remaining **USB HID Ports**, located on the front of the **KVM Switch**.
12. (Optional) Connect **Speakers, Headphones**, or similar **Loudspeaker Device** to the **3.5mm Audio Output**, located on the rear of the **KVM Switch**, using a **3.5mm TRS Audio Cable** (sold separately).

## Connect the PCs

1. Use a **DisplayPort Cable** (sold separately) to connect a **DisplayPort Source Device** to the **DisplayPort Input**, located on the rear of the **KVM Switch**.
2. Connect a **USB to USB Type-B Cable** (sold separately) from a **USB Port** on the **Computer** to the **PC 1 USB Host Connection**, located on the rear of the **KVM Switch**.
3. (Optional) Connect a **3.5mm Audio Cable** (sold separately) from a **3.5mm Audio Output** on the **Computer** to the **PC 1 Audio Input**, located on the rear of the **KVM Switch**.
4. Repeat **Steps 1 to 3** for the remaining **PCs**.



5. Connect the included **Power Adapter** from an available **Wall Outlet** to the **DC Power Input Port**, located on the rear of the **KVM Switch**.
6. Power on all connected **Peripheral Devices**

## Hotkey Commands

Hotkey commands are keystroke sequences that initiate computer/device functions. Hotkey commands can be used to initiate KVM Switch functions. A hotkey command sequence must be initiated by the HK\_LCode, followed by 1-2 additional keystrokes. Successful hotkey command inputs result in a beep.

### Notes:

- All keystroke combinations must be entered in rapid succession.
- Press and release the indicated keys, unless otherwise specified.
- Numbers entered during the hotkey sequence cannot be entered using a number pad.

## Hotkey Leading Code

### Option 1

- Scr Lck + Scr Lck

To change the leading hotkey, perform the following:

- Scr Lck + Scr Lck + H + Caps Lck or Num Lck or F12
- Press and hold PC Selection Button 8 until the KVM Switch emits 2 beeps. Release the PC Selection Button and press the preferred leading key (Scr Lck, Caps Lck, Num Lck, or F12)

Hotkey Command	Function
<b>HK_LCode + 01 ~ 08</b>	<ul style="list-style-type: none"> <li>Select PC 1 ~ PC 8</li> </ul>
<b>HK_LCode + S</b>	<ul style="list-style-type: none"> <li>Start Auto Scan</li> <li>To stop Auto Scan, press any key</li> </ul>
<b>HK_LCode + Up Arrow or Down Arrow</b>	<ul style="list-style-type: none"> <li>Manually switch back and forth between PC Ports</li> </ul>
<b>HK_LCode + S + 1 ~ 0</b>	<ul style="list-style-type: none"> <li>Adjust Auto Scan Rate:               <ul style="list-style-type: none"> <li>1 = 10 seconds</li> <li>2 = 20 seconds</li> <li>3 = 30 seconds</li> <li>4 = 40 seconds</li> <li>5 = 50 seconds</li> <li>6 = 60 seconds</li> <li>7 = 70 seconds</li> <li>8 = 80 seconds</li> <li>9 = 90 seconds</li> <li>0 = 100 seconds</li> </ul> </li> </ul>
<b>HK_LCode + B</b>	<ul style="list-style-type: none"> <li>Enables or Disables the audible beep during Auto Scan</li> <li>Enabled by default</li> </ul>
<b>HK_LCode + Backspace</b>	<ul style="list-style-type: none"> <li>Switch to the last active PC Port</li> </ul>



## Warranty Information

This product is backed by a two-year warranty.

For further information on product warranty terms and conditions, please refer to [www.startech.com/warranty](http://www.startech.com/warranty).

## Limitation of Liability

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product.

Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.

## Hard-to-find made easy. At StarTech.com, that isn't a slogan. It's a promise.

StarTech.com is your one-stop source for every connectivity part you need. From the latest technology to legacy products — and all the parts that bridge the old and new — we can help you find the parts that connect your solutions.

We make it easy to locate the parts, and we quickly deliver them wherever they need to go. Just talk to one of our tech advisors or visit our website. You'll be connected to the products you need in no time.

Visit [www.startech.com](http://www.startech.com) for complete information on all StarTech.com products and to access exclusive resources and time-saving tools.

StarTech.com is an ISO 9001 Registered manufacturer of connectivity and technology parts. StarTech.com was founded in 1985 and services a worldwide market.

### Reviews

Share your experiences using StarTech.com products, including product applications and setup, what you love about the products, and areas for improvement.



**StarTech.com Ltd.**  
45 Artisans Crescent  
London, Ontario  
N5V 5E9  
Canada

**StarTech.com LLP**  
4490 South Hamilton  
Road  
Groveport, Ohio  
43125  
U.S.A.

**StarTech.com Ltd.**  
Unit B, Pinnacle 15  
Gowerton Road Brackmills,  
Northampton  
NN4 7BW  
United Kingdom

**StarTech.com Ltd.**  
Siriusdreef 17-27  
2132 WT Hooftdorp  
The Netherlands