

Wireless-N 150Mbps USB 2.0 AirPrint™ Server

PM1115UA



*actual product may vary from photos

DE: Bedienungsanleitung - de.startech.com

FR: Guide de l'utilisateur - fr.startech.com

ES: Guía del usuario - es.startech.com

IT: Guida per l'uso - it.startech.com

NL: Gebruiksaanwijzing - nl.startech.com

PT: Guia do usuário - pt.startech.com

For the most up-to-date information, please visit: www.startech.com

FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by StarTech.com could void the user's authority to operate the equipment.

Industry Canada Statement

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe [B] est conforme à la norme NMB-003 du Canada.

CAN ICES-3 (B)/NMB-3(B)

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

IC Radiation Exposure Statement

This equipment complies with IC RSS-102 radiation exposure limit set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0.5cm between the radiator and your body.

Déclaration d'exposition à la radiation

Cet équipement respecte les limites d'exposition aux rayonnements IC définies pour un environnement non contrôlé. Cet équipement doit être installé et mis en marche à une distance minimale de 0.5 cm qui sépare l'élément rayonnant de votre corps.

L'émetteur ne doit ni être utilisé avec une autre antenne ou un autre émetteur ni se trouver à leur proximité.

FCC ID: U9XKCODES-901

IC: 11232A-PM1115UA

The Country Code Selection feature is disabled for products marketed in the US/Canada

Co-located

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols

This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of third-party companies not related in any way to StarTech.com. Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by StarTech.com, or an endorsement of the product(s) to which this manual applies by the third-party company in question. Regardless of any direct acknowledgement elsewhere in the body of this document, StarTech.com hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders.

Table of Contents

Introduction	1
Packaging Contents	1
System Requirements.....	1
Installation	1
Hardware Installation	1
Software Installation.....	1
Operation	6
Printing Using AirPrint™.....	6
Adding a Printer.....	6
Reset to the default factory settings.....	8
Technical Support	9
Warranty Information	9

Introduction

Packaging Contents

- 1 x Wireless-N USB 2.0 AirPrint™ Server
- 1 x Universal Power Adapter (NA/UK/EU)
- 1 x Driver CD
- 1 x Instruction Manual

System Requirements

- Windows® 8 / 8.1 (32/64bit), 7 (32/64), Vista(32/64), XP(32/64), Windows Server® 2012, 2008 R2, 2003(32/64), Mac OS® 10.8 and up (tested up to 10.10)

Installation

Hardware Installation

1. Power off the printer that will be used with the print server and leave the print server power adapter disconnected.
2. Connect your printer to the USB port on the print server.
3. Power on your printer so it is ready for use.
4. Connect the Power Adapter to the print server - the Power LED will light up. When the LAN indicator lights up, the print server is correctly connected to the network.


Software Installation

To configure the print server to be used with a PC or Mac, you need to install the included software, outlined in the steps below.

Windows

1. Connect a Cat 5 (or better) Ethernet cable to the LAN port on the print server, then to your router / network.
Note: The initial configuration must be done from a wired connection. When the device is connected to an existing access point and set with the proper IP settings for your wireless network, you can disconnect the LAN cable.
2. On the computer that is connected to the same router/network, insert the included CD into your CD/DVD drive.
3. Browse to the **Windows** folder and run the **Setup.exe** application.

4. Follow the on-screen instructions to complete the installation.
5. Start the **USB Device Server Control Center** to search for available print servers on the network.
6. Select your print server from the list and click **Configure Server**.



7. Log in with your username / password (default: **admin / admin**).
8. Configure your desired IP address (Static / DHCP), user account name / password and security settings.
Note: To prevent unauthorized access / changes to the print server, you should change the default username / password used to log into the device, and to enable encryption on the wireless connection.
9. If you want to connect the print server to the network wirelessly, click the **Connect to Another AP** button to view a list of available networks and select the access point that you want the server to connect to.

Wireless

SSID

Broadcast SSID:

Band:

Channel Number:

Encryption:


AP

State Not Connected

10. After the wireless connection is established, the LAN cable can be disconnected from the print server.

Mac OS

1. Connect a Cat 5 (or better) Ethernet cable to the LAN port on the print server, then to your router / network.
Note: The initial configuration must be done from a wired connection. When the device is connected to an existing access point and set with the proper IP settings for your wireless network, you can disconnect the LAN cable.
2. On the computer that is connected to the same router/network, insert the provided CD into your DVD/CD-ROM drive.
3. Browse to your DVD/CD-ROM drive, then to the **Mac OS** folder on the disc.
4. Mount the **StarTech.com USB Device Server Control Center Installer.dmg** file, and then run the **StarTech.com USB Device Server Control Center Installer.pkg** application to start the installation.
5. Follow the on-screen instructions to complete the installation.
6. Start the **USB Device Server Control Center** to search for available print servers on the network.
7. Select your print server from the list and click the **Home** button to configure the server.



8. Log in with your username / password (default: **admin / admin**).
9. Configure your desired IP address (Static / DHCP), user account name / password and security settings.
Note: To prevent unauthorized access / changes to the print server, you should change the default username / password used to log into the device, and to enable encryption on the wireless connection.
10. If you want to connect the print server to the network wirelessly, click the **Connect to Another AP** button to view a list of available networks and select the access point that you want the server to connect to.

Wireless

SSID

Broadcast SSID:

Band:

Channel Number:

Encryption:

AP

State Not Connected

11. After the wireless connection is established, the LAN cable can be disconnected from the print server.

Operation

Printing Using AirPrint™

AirPrint is an Apple technology that lets you print wirelessly from your iOS device, without the need to download or install drivers.

Supported devices:


- iPad (all models)
- iPhone (3GS or later)
- iPod touch (3rd generation or later)
 1. Ensure that your iOS device is connected to the same wireless access point that the print server is using.
 2. Tap the  or  icons, which are at the bottom of your screen.
 3. Tap the printer icon (.
 4. Choose your printer, the number of copies you want, and then tap Print.

Note: If you are printing for the first time, ensure that you are within range of your printer. All AirPrint-enabled printers within range will be displayed.

Adding a Printer

Windows

1. Start the USB Device Server Control Center software and allow it to find the print server on your LAN / Wireless connection.
2. Select the printer that you would like to connect and click the **Connect** button to automatically map the network printer. If this is the first time you're connecting the printer, Windows may take a moment to install the printer and detect / prompt for drivers.




Note: Only one PC at a time can Connect the printer using this method

3. Once you are done using the printer, click the **Disconnect** button.

Auto-Connecting the Printer

The print server also supports an Auto-Connect function so that you don't have to connect / disconnect manually, after the driver for the printer has been installed (i.e. after the first manual connect operation or physical connection to the computer).

1. In the USB Device Server Control Center Software, click **Auto-Connect Printer**, then **Set Auto-Connect Printer**.



2. In the window that opens, select your printer and click **Apply**.


3. When you send a print job, the software will automatically connect the printer and send the print job to it, as long as the control center software is running.

Mac OS

1. Start the USB Device Server Control Center software and allow it to find the print server on your LAN / Wireless connection.
2. Select the printer that you would like to connect and click the **Connect** button to automatically map the network printer. If this is the first time you're connecting the printer, Mac OS may take a moment to install the printer and detect / prompt for drivers

Note: Only one PC at a time can connect to the printer using this method


3. Once you are done using the printer, click the **Disconnect** button.



Auto-Connecting the Printer

The print server also supports an Auto-Connect function so that you don't have to connect / disconnect manually, after the driver for the printer has been installed (i.e. after the first manual connect operation or physical connection to the computer).

1. In the USB Device Server Control Center Software, click the **Auto-Connect** button.



2. In the window that opens, select your printer and click **Apply**.
3. When you send a print job, the software will automatically connect the printer and send the print job to it, as long as the control center software is running.

For complete operating instructions, please visit www.startech.com/PM1115UA.

Reset to the default factory settings

To reset the print server to the default factory settings, while the print server is turned on, press and hold the **INIT** button for 15 seconds. The print server automatically reboots with the default factory settings.

Technical Support

StarTech.com's lifetime technical support is an integral part of our commitment to provide industry-leading solutions. If you ever need help with your product, visit www.startech.com/support and access our comprehensive selection of online tools, documentation, and downloads.

For the latest drivers/software, please visit www.startech.com/downloads

Warranty Information

This product is backed by a two year warranty.

In addition, StarTech.com warrants its products against defects in materials and workmanship for the periods noted, following the initial date of purchase. During this period, the products may be returned for repair, or replacement with equivalent products at our discretion. The warranty covers parts and labor costs only. StarTech.com does not warrant its products from defects or damages arising from misuse, abuse, alteration, or normal wear and tear.

Limitation of Liability

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.

Hard-to-find made easy. At StarTech.com, that isn't a slogan. It's a promise.

StarTech.com is your one-stop source for every connectivity part you need. From the latest technology to legacy products — and all the parts that bridge the old and new — we can help you find the parts that connect your solutions.

We make it easy to locate the parts, and we quickly deliver them wherever they need to go. Just talk to one of our tech advisors or visit our website. You'll be connected to the products you need in no time.

Visit www.startech.com for complete information on all StarTech.com products and to access exclusive resources and time-saving tools.

StarTech.com is an ISO 9001 Registered manufacturer of connectivity and technology parts. StarTech.com was founded in 1985 and has operations in the United States, Canada, the United Kingdom and Taiwan servicing a worldwide market.