

STUTPRXWAL
STUTPTXWAL
STUTPWALL
Instruction Manual

VGA Video Extender over CAT5

**VGA Wall Plate Video Extender
over CAT5 Receiver**

**VGA Wall Plate Video Extender
over CAT5 Transmitter**

StarTech.com 
Making hard-to-find easy!®

FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols

This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of third-party companies not related in any way to StarTech.com. Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by StarTech.com, or an endorsement of the product(s) to which this manual applies by the third-party company in question. Regardless of any direct acknowledgement elsewhere in the body of this document, StarTech.com hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders.

Table of Contents

Introduction	1
Packaging Contents.....	1
System Requirements	1
Installation	2
Transmitter Unit (STUTPTXWAL)	2
Receiver Unit (STUTPRXWAL)	3
Hardware Installation.....	4
Wiring Information and Coding	5
Distances and Resolutions	6
Adapter Output Polarity	6
Specifications	7
Technical Support	8
Warranty Information	8

Introduction

Packaging Contents

- 1 x STUTPTXWAL (transmitter) or STUTPRXWAL (receiver)
* both units included in STUTPWALL kit
- 1 x Power Adapter
* 2 included in STUTPWALL kit
- 1 x User Manual
- 1 x Terminal Block adapter for power adapter
* 2 included in STUTPWALL kit

System Requirements

- Open wall receptacle for unit installation
- Available power outlet
- Both Transmitter (STUTPTXWAL) and Receiver (STUTPRXWAL) units

Installation

Transmitter Unit (STUTPTXWAL)


Front View



* picture may vary from actual product

- DE-15 Female Connector
- Power LED
- Control H/V signal inverting switch
 - The default setting of H-INV is “OFF”. If H-INV is set to “ON”, the horizontal signal output is adjusted. H-INV on the receiver must also be set to “ON”.
 - The default setting of V-INV is “OFF”. If V-INV is set to “ON”, the vertical signal output is adjusted. V-INV on the receiver must also be set to “ON”.
 - Use this setting when noise or sync issues are detected in the signal transfer.

Rear View



* picture may vary from actual product

- Power Connector
- RJ-45Female Connector

Receiver Unit (STUTPRXWAL)

Front View




* picture may vary from actual product

- DE-15 Female Connector
- EQ – Equalization length adjust (Adjust sharpness)
- GAIN – Adjust brightness
- Power LED
- Control H/V signal inverting switch

- The default setting of H-INV is “OFF”. If H-INV is set to “ON”, the horizontal signal output is adjusted. H-INV on the transmitter must also be set to “ON”.
- The default setting of V-INV is “OFF”. If V-INV is set to “ON”, the vertical signal output is adjusted. V-INV on the transmitter must also be set to “ON”.
- Use this setting when noise or sync issues are detected in the signal transfer.

Rear View




* picture may vary from actual product

- Power Connector
- RJ-45Female Connector

Hardware Installation

1. Turn off the PC and remote monitor.
2. Connect STUTPTXWAL Transmitter unit DE-15 female input connector with DE-15 male to male cable to PC video card.
3. Connect STUTPTXWAL Transmitter and STUTPRXWAL Receiver unit together with CAT5 cable.
4. Connect STUTPRXWAL Receiver unit DE-15 female connector with DE-15 male to male cable to monitor.
5. Connect the power adapter on each unit.
6. Turn on the monitor and PC.

Wiring Information and Coding




Conductor	RJ45 Pin	Conductor Colour Code
Pair 1	5	White-Blue
	4	Blue
Pair 2	1	White-Orange
	2	Orange
Pair 3	3	White-Green
	6	Green
Pair 4	7	White-Brown
	8	Brown

Distances and Resolutions

CAT5/CAT5e	50m	1920x1200
	100m	1600x1200
	180m	1280x1024
	200m	1024x768
	300m	800x600
CAT6	30m	1920x1440
	50m	1280x1024
	100m	800x600

Adapter Output Polarity



Pin	Output Level	Conductor Colour
1	+12V	Black-White
2	RTN (-)	Black

Specifications

Video Connector	15-pin D-Sub (DE-15)
Rear Connectors	RJ45 Terminal Block
Maximum Resolution	1920x1200 at 60Hz
Maximum Distance	300 meters at 800x600
Power Adapter Output	12VDC, 600mA
Material	Metal
Color	White
Weight	165 g (transmitter) 170 g (receiver)
Dimensions	78.2 mm x 41.2 mm x 52.8 mm

Technical Support

StarTech.com's lifetime technical support is an integral part of our commitment to provide industry-leading solutions. If you ever need help with your product, visit www.startech.com/support and access our comprehensive selection of online tools, documentation, and downloads.

Warranty Information

This product is backed by a one year warranty.

In addition, StarTech.com warrants its products against defects in materials and workmanship for the periods noted, following the initial date of purchase. During this period, the products may be returned for repair, or replacement with equivalent products at our discretion. The warranty covers parts and labor costs only. StarTech.com does not warrant its products from defects or damages arising from misuse, abuse, alteration, or normal wear and tear.

Limitation of Liability

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.



StarTech.com has been making “hard-to-find easy” since 1985, providing high quality solutions to a diverse IT and A/V customer base that spans many channels, including government, education and industrial facilities to name just a few. We offer an unmatched selection of computer parts, cables, A/V products, KVM and Server Management solutions, serving a worldwide market through our locations in the United States, Canada, the United Kingdom and Taiwan.

Visit **www.startech.com** today for complete information about all our products and to access exclusive interactive tools such as the Cable Finder, Parts Finder and the KVM Reference Guide.