


To update the firmware on the unit, start by opening the USB Server software then ***right click*** on the server and select “***Server Configurations***”



Select “***Update Firmware***”

Server Configurations

Network Setting :

Server Name : USB Server

☒ Use DHCP

IP Address : 192 . 168 . 1 . 73

Subnet : 255 . 255 . 255 . 0

Connect automatically by port

☐ Port 1 ☐ Port 2 ☐ Port 3 ☐ Port 4

Set Cancel

Backup Firmware

Update Firmware

Change Password

Restart Server

Select the firmware file from the download and click open to finish

You might get an error that the update failed, but power cycle the device and you should now see it listed as 2.078.000 on the devices website after the reboot.