











1. Double click on the FirmwareUpdate.exe file to begin the process

Name	Date modified	Type	Size
 FirmwareUpdate.exe	10/14/2016 5:03 PM	Application	568 KB
 FlashImage_E2868_E3868_USBServer_2_06...	8/26/2016 10:50 AM	BIN File	512 KB
 PT2Config.ini	4/17/2017 10:28 AM	Configuration sett...	1 KB
 PT2English.dll	10/14/2016 5:03 PM	Application extens...	220 KB
 PTdcp.dll	10/14/2016 5:03 PM	Application extens...	176 KB
 PTlog.dll	10/14/2016 5:03 PM	Application extens...	84 KB
 PTpsm.dll	10/14/2016 5:03 PM	Application extens...	124 KB
 PTuntp.dll	10/14/2016 5:03 PM	Application extens...	108 KB
 USB1000IP_firmware.zip	4/17/2017 11:15 AM	Compressed (zipp...	699 KB

2. Click on “Program” to update the firmware on the device.



3. If the device is found on the network you will see it listed in the “Server” box. Copy the MAC address from this box to the MAC Settings field above

Program

MAC Settings

2

☐ Use barcode scanner

MAC

00

:

00

:

00

:

00

:

00

:

00

Clear

Next

Server

MAC	IP
00:50:62:10:0C:32	192.168.208.25

1

Search

Burn Flash

Source :

./FlashImage\_E2868\_E3868\_USBServer\_2\_068\_000.bin

Burn

3

Tester Input

Worker ID:

Batch ID:

All Count:

Current count:

OK count:

Fail count:

Buring Result

Advance

Exit

- Click the “Burn” button and the process will start. If all goes well you should see the message “OK”. Reboot your device to make sure that the new firmware is loaded

Program

MAC Settings

☐ Use barcode scanner

MAC  :  :  :  :  :

Server

MAC	IP
00:50:62:10:0C:32	192.168.208.25

Burn Flash

Done

Source :  
./FlashImage\_E2868\_E3868\_USBServer\_2\_068\_000.bin

Tester Input

Worker ID:

Batch ID:

All Count:

Current count:

OK count:

Fail count:

Buring Result

OK