


4U Storage Drawer for 19" Server Racks

Product ID
4UDRAWER



*Product may vary from image

Component		Function
1	Drawer Key Lock	<ul style="list-style-type: none">Use the included Set of Keys to Lock or Unlock the DrawerRev 02 and above only
2	Drawer Handle	<ul style="list-style-type: none">Use to Open or Close the Drawer
3	Mounting Brackets	<ul style="list-style-type: none">Fasten the Drawer to the Front Posts of the Rack or CabinetTwo Mounting Holes on each side of the Drawer allow for rack mounting

How to Identify the LOT Code Revision Number

The Revision Number (Rev #) appears as the fifth and sixth digits of the LOT code, located on the sticker affixed to the product and its packaging. If the LOT code sticker is missing, the product is Rev 01.

Requirements

For the latest drivers/software, technical specifications, and declarations of conformance, please visit: www.StarTech.com/4UDRAWER

- Phillips Head Screwdriver

Package Contents

- 4U Storage Drawer x 1
- M5 (Rev 01) or M6 (Rev 02 and Above) Screws and Cage Nuts x 4
- Plastic Washers x 4 (Rev 02 and Above)
- Set of Keys x 1 (Rev 02 and Above)

Installation

Warnings!

Read the entire Quick-Start Guide and ensure the instructions are fully understood before assembling and using this product. Before adding equipment to this product, ensure this product has been properly mounted. Never operate this product if parts are missing or damaged. Ensure the weight of the equipment does not exceed the weight capacity of this product. If the weight capacity is exceeded, personal injury or damage to the equipment is possible. This product can support 55.1 lb (25 kg). The maximum supported weight is only possible when both mounting brackets are properly mounted to two front posts on a rack. Arrange your equipment in the rack in descending order of weight. The lightest equipment is installed at the top of the rack, and the heaviest is on the bottom.

1. Locate a suitable section in the **Rack/Cabinet** to mount the **4U Storage Drawer**. The **Drawer** itself requires **4U** of space within the **Rack** or **Cabinet**.
2. (Optional) If the **Rack** uses **Square Mounting Holes**, install the included **Cage Nuts** into the **Square Mounting Holes** on the **Front Posts** of the **Rack**.
3. Place the **Drawer** into the **Rack** and align the **Mounting Holes** on the **Mounting Brackets** of the **Drawer** with the **Mounting Holes** on the **Rack** (e.g. the cage nuts, if used).
4. Use a **Phillips Head Screwdriver**, and the included **M5** or **M6 Screws** and **Plastic Washers** to secure the **Drawer** to the **Rack**.

5. Ensure the **M5** or **M6 Screws** are properly tightened and the **Drawer** has no movement before placing anything inside.

PHILLIPS® is a registered trademark of Phillips Screw Company in the United States or other countries.

For further information on product warranty terms and conditions, please refer to www.startech.com/warranty.

Monteer dit product volgens de instructies. Lees de gehele handleiding en zorg ervoor dat u de instructies volledig begrijpt voordat u dit product monteert en/of gebruikt.

Monte este producto siguiendo las instrucciones. Lea todo el manual y asegúrese de que las instrucciones se entienden completamente antes de montar y/o utilizar este producto.



FR: startech.com/fr
DE: startech.com/de
ES: startech.com/es
NL: startech.com/nl
IT: startech.com/it
JP: startech.com/jp