

2 Port PCI Express Internal SATA II Controller Card

PEXSATA22I



DE: Bedienungsanleitung - de.startech.com

FR: Guide de l'utilisateur - fr.startech.com

ES: Guía del usuario - es.startech.com

IT: Guida per l'uso - it.startech.com

NL: Gebruiksaanwijzing - nl.startech.com

PT: Guia do usuário - pt.startech.com

FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols

This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of third-party companies not related in any way to StarTech.com. Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by StarTech.com, or an endorsement of the product(s) to which this manual applies by the third-party company in question. Regardless of any direct acknowledgement elsewhere in the body of this document, StarTech.com hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders.

Table of Contents

Introduction	1
Package contents.....	1
System Requirements	1
Installation.....	2
Driver Installation (Non-boot drives)	3
Verifying Successful Driver Installation.....	3
Windows Vista™ Fresh Installation.....	4
Windows 2000/XP/2003 Server Fresh Installation.....	4
Specifications.....	6
Technical Support.....	7
Warranty Information.....	7
Screen Quality & Pixel Policy.....	7

Introduction

Thank you for purchasing a StarTech.com SATA II PCI Express Adapter. Supporting SATA II data transfer speeds of up to 3.0 Gbps, this dual port SATA II PCI Express Card offers users a cost-effective solution for connecting additional SATA II drives and provides RAID capable operation.

Features

- Provides two internal SATA II connections
- Supports two independent SATA II channels (separate logic and FIFO)
- Supports Native Command Queue (NCQ) operation
- Supports 1-Lane 2.5Gbps Express bus

Package contents

This package should contain:

- 1 x PCI Express SATA adapter card
- 1 x Driver CD
- 1 x Instruction Manual
- 1 x Low Profile Bracket

System Requirements

- Microsoft® Windows® 2000/XP/2003/Vista™/ 7 (32/64-bit) or Linux®
- PCI Express enabled computer system with available PCI Express slot

Installation



WARNING! PCI Express cards, like all computer equipment, can be severely damaged by static electricity. Be sure that you are properly grounded before opening your computer case or touching your card. StarTech.com recommends that you wear an anti-static strap when installing any computer component. If an anti-static strap is unavailable, discharge yourself of any static electricity build-up by touching a large grounded metal surface (such as the computer case) for several seconds. Also be careful to handle the card by its edges and not the gold connectors.

Please note: If you are performing a new operating system installation and wish to boot from one of the drives being connected to PEXSATA22I, please copy the following files from the included Driver CD to a blank floppy disk that can be used during OS installation:

jgogo.sys

jraid.cat

Jraid.sys

jraid_f.inf

txtsetup.oem

For further instruction on how to install the card and necessary drivers for use with a fresh (boot) OS drive, please skip to the section entitled **Windows Vista™ Fresh Installation** or **Windows 2000/XP/2003 Server Fresh Installation** as applicable. Otherwise, if you will be installing PEXSATA22I to connect a secondary (non-boot) drive, proceed as follows:

1. Shut down all power connected to the computer, as well as all devices connected to the computer peripherally (i.e. Printers, Monitors, Scanners etc.). As an added step to ensure safe installation, unplug the power supply from the computer.
2. Remove the computer cover, allowing access to the motherboard and available slots. For more detailed instruction on how to perform this step, please refer to the documentation that was included with your computer at the time of purchase.
3. Locate an empty PCI Express slot, removing the metal bracket covering the accompanying empty port/socket on the rear panel of the computer chassis.
4. Position the card above the open PCI Express slot, ensuring that the card is properly aligned with the slot. Insert the card firmly into the slot, distributing force evenly across the length of the board.

Once inserted, secure the card into the adjoining socket (previously covered by metal bracket, on the rear panel of the computer chassis), using the correct size screw (if necessary, please consult documentation that accompanied purchase of computer).

5. Connect the desired SATA drives.

Driver Installation (Non-boot drives)

1. Power on the computer.
2. Locate and execute the Setup.exe file on the Driver CD (included). This program will copy driver files onto the host system. If you wish to perform the installation manually, please ensure that you have specified the correct file when asked (titled: **JMB36X_WinDrv_WHQL_R1.17.31WHQL\R1.17.31.00\Driver\x32\raid_i.inf**). Once the files have been copied, restart your computer as prompted.
3. After the system reboots, Windows will locate the new hardware RAID Controller and install the necessary driver.
4. Replace the computer chassis, and power on the computer.

Verifying Successful Driver Installation

Once the computer has been powered on following the driver installation and the connection of the desired drive, you may wish to verify that the necessary files have been installed properly. To do so:

1. Right-click on **My Computer** and select **Manage**.
2. In the left pane of the Computer Management window, select **Device Manager**.
3. In the right pane of the Computer Management window, click on **SCSI and RAID Controllers**. Here, you should find listed **JMicron JMB36X RAID Controller** and **JMicron JMB36X RAID Processor**, upon successful installation.

Windows Vista™ Fresh Installation

Follow the instructions in this section if you are performing a new (bootable) installation of Windows Vista™ on a drive attached to PEXSATA21:

1. Shut down all power connected to the computer, as well as all devices connected to the computer peripherally (i.e. Printers, Monitors, Scanners etc.). As an added step to ensure safe installation, unplug the power supply from the computer.
2. Remove the computer cover, allowing access to the motherboard and available slots. For more detailed instruction on how to perform this step, please refer to the documentation that was included with your computer at the time of purchase.
3. Locate an empty PCI Express slot, removing the metal bracket covering the accompanying empty port/socket on the rear panel of the computer chassis.
4. Position the card above the open PCI Express slot, ensuring that the card is properly aligned with the slot. Insert the card firmly into the slot, distributing force evenly across the length of the board.

Once inserted, secure the card into the adjoining socket (previously covered by metal bracket, on the rear panel of the computer chassis), using the correct size screw (if necessary, please consult documentation that accompanied purchase of computer).

5. Attach PEXSATA22I to the Serial ATA drive, using a SATA (data) cable. Similarly, attach an available SATA power connector (provided by computer power supply) to the drive.
6. Repeat steps 4 and 5 for each remaining hard drive that will be connected to PEXSATA22I.
7. Replace the computer cover and re-connect all power to the computer.
8. Start the computer as you normally would to perform an operating system installation, ensuring that the Windows Vista™ installation CD/DVD is present in the drive, and the BIOS has been suitably adjusted to boot from the CD/DVD Drive.
9. When the Windows Install screen appears, fill in the necessary information and click Next. Follow the operating system instructions until a page appears asking “**Where do you want to install Windows?**”. From here, click on **Load Driver**.
10. You will then be asked to provide the necessary driver files. The files can be accessed by CD, DVD, or USB Flash Drive. As such, connect the drivers to the computer using one of these methods, and click **Browse** to specify the location of the files. Then, click **Next**.
11. Windows Vista™ will then install the necessary files, after which the drive connected to PEXSATA22I will be recognized as a usable drive.
12. Select the drive on which you wish to install the operating system, and click Next, to resume normal operating system installation

Windows 2000/XP/2003 Server Fresh Installation

Follow the instructions in this section if you are performing a new installation of Windows 2000/XP/2003, and you wish to boot from a drive attached to PEXSATA22I.

Note: Ensure you've created the necessary boot disk (as outlined on page 2) prior to installation, as it will be required in order to properly conduct the OS installation.

1. Shut down all power connected to the computer, as well as all devices connected to the computer peripherally (i.e. Printers, Monitors, Scanners etc.). As an added step to ensure safe installation, unplug the power supply from the computer.
2. Remove the computer cover, allowing access to the motherboard and available slots. For more detailed instruction on how to perform this step, please refer to the documentation that was included with your computer at the time of purchase.

3. Locate an empty PCI Express slot, removing the metal bracket covering the accompanying empty port/socket on the rear panel of the computer chassis.
4. Position the card above the open PCI Express slot, ensuring that the card is properly aligned with the slot. Insert the card firmly into the slot, distributing force evenly across the length of the board.

Once inserted, secure the card into the adjoining socket (previously covered by metal bracket, on the rear panel of the computer chassis), using the correct size screw (if necessary, please consult documentation that accompanied purchase of computer).

5. If a floppy drive is available on the host system, attach PEXSATA22I to the Serial ATA drive(s), using a SATA (data) cable. If no floppy drive is available, please skip to the section entitled **Installation Without a Floppy Drive**.
6. Repeat steps **1-5** for the remaining hard drives that will be connected as necessary.
7. Replace the computer cover and re-connect all power to the computer.
8. Turn on the computer. Upon first boot, Windows will instruct you to Press [**F6**] for third party SCSI or driver installation. As such, please hit [**F6**] to continue.
9. Press [**S**] when setup asks if you want to specify an additional device, and insert the boot diskette into your floppy drive, then press [**Enter**]

Select [**JMicron Serial ATA Adapter**], then press [**Enter**].

Press [**Enter**] again to finish driver installation, then follow the on-screen instructions to complete the Windows installation.

Please note: If a Security Alert warning pops up, click Yes to proceed. Follow the setup instructions to select your choice for partition and file system. After setup examines your disks, it will copy files from the CD to the hard drive selected above, and restart the system. After restart, the setup process will resume installing the new drive(s).

Specifications

Bus Interface	PCI Express 1.0a (x1 connector)
Chipset	JMicron JMB363
Connectors	2 x SATA 7-pin male
Maximum Data Transfer Rate	3Gbps
Compatible Operating Systems	Windows 2000/XP/Server 2003/Vista/7 (32/64-bit), Linux
Regulatory Certifications	CE/FCC/ROHS
Weight	44.2 g (1.42 oz)
Dimensions (L x W x H)	102 x 120 x 20mm (1.7 x 4.74 x .78")

Technical Support

StarTech.com's lifetime technical support is an integral part of our commitment to provide industry-leading solutions. If you ever need help with your product, visit www.startech.com/support and access our comprehensive selection of online tools, documentation, and downloads.

Warranty Information

This product is backed by a lifetime warranty.

In addition, StarTech.com warrants its products against defects in materials and workmanship for the periods noted, following the initial date of purchase. During this period, the products may be returned for repair, or replacement with equivalent products at our discretion. The warranty covers parts and labor costs only. StarTech.com does not warrant its products from defects or damages arising from misuse, abuse, alteration, or normal wear and tear.

Limitation of Liability

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.

StarTech.com

Hard-to-find **made easy**®

Hard-to-find made easy. At StarTech.com, that isn't a slogan. It's a promise.

StarTech.com is your one-stop source for every connectivity part you need. From the latest technology to legacy products — and all the parts that bridge the old and new — we can help you find the parts that connect your solutions.

We make it easy to locate the parts, and we quickly deliver them wherever they need to go. Just talk to one of our tech advisors or visit our website. You'll be connected to the products you need in no time.

Visit **www.startech.com** for complete information on all StarTech.com products and to access exclusive resources and time-saving tools.

StarTech.com is an ISO 9001 Registered manufacturer of connectivity and technology parts. StarTech.com was founded in 1985 and has operations in the United States, Canada, the United Kingdom and Taiwan servicing a worldwide market.