



## 2-Port Triple/Quad Monitor KVM Switch - DisplayPort™ - 4K 60Hz

### Product Diagram (SV231TDPU34K/SV231QDPU34K)

Front View



Rear View



Port	Function
1	Console USB HID Ports <ul style="list-style-type: none"> <li>Connect up to 4 <b>USB Human Interface Devices (HID)</b> (e.g. Keyboard, Mouse, Trackpad, Number Keypad, Drawing Tablet)</li> </ul>
2	Console USB Hub Ports <ul style="list-style-type: none"> <li>Connect up to 2 <b>SuperSpeed USB 5Gbps (USB 3.2 Gen 1) Peripheral Devices</b></li> </ul>

3	Port Selection LED Indicators <ul style="list-style-type: none"> <li>Green: <b>PC 1</b> and/or <b>PC 2</b> connected (power on)</li> <li>Red: <b>PC 1</b> or <b>PC 2</b> selected (power on)</li> </ul>
4	Port Selection Button <ul style="list-style-type: none"> <li>Press the <b>Port Selection Button</b> to select <b>PC 1</b> or <b>2</b></li> </ul>
5	Console DisplayPort Output Ports <ul style="list-style-type: none"> <li>(SV231TDPU34K) Connect to three <b>Console DisplayPort Displays</b></li> <li>(SV231QDPU34K) Connect to four <b>Console DisplayPort Displays</b></li> </ul>
6	PC 2 DisplayPort Input Ports <ul style="list-style-type: none"> <li>(SV231TDPU34K) Connect to three <b>DisplayPort Ports</b> on <b>PC 2</b></li> <li>(SV231QDPU34K) Connect to four <b>DisplayPort Ports</b> on <b>PC 2</b></li> </ul>
7	PC 1 DisplayPort Input Ports <ul style="list-style-type: none"> <li>(SV231TDPU34K) Connect to three <b>DisplayPort Ports</b> on <b>PC 1</b></li> <li>(SV231QDPU34K) Connect to four <b>DisplayPort Ports</b> on <b>PC 1</b></li> </ul>
8	Power Input Port <ul style="list-style-type: none"> <li>Connect a <b>DC 12V Power Source</b> to power the <b>KVM Switch</b></li> </ul>
9	Console Audio Port <ul style="list-style-type: none"> <li>Connect an <b>Audio Device</b> (Stereo Speakers or Microphone)</li> </ul>
10	PC 2 USB Port <ul style="list-style-type: none"> <li>Connect to a <b>SuperSpeed USB 5Gbps (USB 3.2 Gen 1) Port</b> on <b>PC 2</b></li> </ul>
11	PC 2 Audio Port <ul style="list-style-type: none"> <li>Connect to an <b>Audio Port</b> (for Stereo Speakers or a Microphone) on <b>PC 2</b></li> </ul>
12	PC 1 USB Port <ul style="list-style-type: none"> <li>Connect to a <b>SuperSpeed USB 5Gbps (USB 3.2 Gen 1) Port</b> on <b>PC 1</b></li> </ul>
13	PC 1 Audio Port <ul style="list-style-type: none"> <li>Connect to an <b>Audio Port</b> (for Stereo Speakers or a Microphone) on <b>PC 2</b></li> </ul>

### Requirements

For the latest requirements and to view detailed instructions on all product functionality in a full user manual, please visit:

[www.startech.com/SV231TDPU34K](http://www.startech.com/SV231TDPU34K)

[www.startech.com/SV231QDPU34K](http://www.startech.com/SV231QDPU34K)

#### Source PCs

- Computers (DisplayPort enabled) x 2
- DisplayPort Cables x 6 (SV231TDPU34K), 8 (SV231QDPU34K)
- SuperSpeed USB 5Gbps (USB 3.2 Gen 1) Cables (Type-A Male to Type-B Male) x 2

- (Optional) 3.5 mm Audio Cables (Male to Male) x 2

## Console

- DisplayPort Displays x 3 (SV231TDP34K), 4 (SV231QDP34K)
- DisplayPort Cables x 3 (SV231TDP34K), 4 (SV231QDP34K)
- USB Keyboard x 1
- USB Mouse x 1
- (Optional) Audio Device (e.g. Headphones, Microphone, etc.) x 1
- (Optional) USB HID Devices x 2
- (Optional) SuperSpeed USB 5Gbps (USB 3.2 Gen 1) Peripheral Devices x 2

## Installation

### Connect the Console

1. Power off the **DisplayPort Display** and any **Peripherals** before connecting to the **KVM Switch**.
2. Connect 3 (SV231TDP34K) or 4 (SV231QDP34K) **DisplayPort Displays** to the **Console DisplayPort Output Ports** on the rear of the **KVM Switch**.
3. Connect a **USB Keyboard** and a **USB Mouse** to the **Console USB HID Ports** on the rear of the **KVM Switch**.
4. (Optional) Connect an additional **USB HID Device** to the remaining **Console USB HID Port** on the front of the **KVM Switch**.
5. (Optional) Connect the **Audio Device** to the **Console Audio Port** on the **KVM Switch**.
6. (Optional) Connect up to two **SuperSpeed USB 5Gbps (USB 3.2 Gen 1) Peripheral Devices** to the **Console USB Hub Ports** located on the front and rear of the **KVM Switch**.

### FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by StarTech.com could void the user's authority to operate the equipment.

### Industry Canada Statement

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe [A] est conforme à la norme NMB-003 du Canada.

CAN ICES-3 (A)/NMB-3(A)

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

(1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

### Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols

This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of third-party companies not related in any way to StarTech.com. Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by StarTech.com, or an endorsement of the product(s) to which this manual applies by the third-party company in question. StarTech.com hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders.

## Connect the PCs

1. Power off the **Computer** and any **Peripherals** before connecting to the **KVM Switch**.
2. Connect 3 (SV231TDP34K) or 4 (SV231QDP34K) **DisplayPort Cables** from the **DisplayPort Ports** on the **Computer** to the **PC 1 DisplayPort Input Ports** on the rear of the **KVM Switch**.
3. Connect a **SuperSpeed USB 5Gbps (USB 3.2 Gen 1) Cable (Type-A Male to Type-B Male)** from the **USB-A Port** on the **Computer** to the **PC 1 USB Port** on the rear of the **KVM Switch**.  
**Note:** A **SuperSpeed USB 5Gbps** (or better) **Cable** is recommended for optimal performance.
4. (Optional) Connect a **3.5 mm Audio Cable** from the **Audio Port** on the **Computer** to the corresponding **PC 1 Audio Port** on the rear of the **KVM Switch**.
5. Repeat steps 1 to 4 for **Source PC 2**.

## Operation

### Power-On Sequence

1. Connect the **Universal Power Adapter** from a **Wall Outlet** to the **Power Input Port** on the **KVM Switch**.
2. Power on all **Peripherals**.
3. Select **PC 1** and power on the corresponding **Computer**.  
**Note:** Ensure that the **Computer** connected to the **PC 1 Ports** has fully booted to the operating system before proceeding.
4. Repeat step 3 for **Source PC 2**.

### Warranty Information

This product is backed by a two-year warranty.

For further information on product warranty terms and conditions, please refer to [www.startech.com/warranty](http://www.startech.com/warranty).

### Limitation of Liability

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.

### Safety Measures

- If product has an exposed circuit board, do not touch the product under power.

### Mesures de sécurité

- Si l'un des circuits imprimés du produit est visible, ne pas touchez le produit lorsqu'il est sous tension.

### 安全対策

- 製品に露出した状態の回路基盤が含まれる場合、電源が入っている状態で製品に触らないでください。

### Misure di sicurezza

- Se il prodotto ha un circuito stampato visibile, non toccare il prodotto quando è acceso.

### Säkerhetsåtgärder

- Rör aldrig vid enheter med oskyddade kretskort när strömmen är påslagen.

<b>StarTech.com Ltd.</b>	<b>StarTech.com LLP</b>	<b>StarTech.com Ltd.</b>	<b>StarTech.com Ltd.</b>	FR: fr.startech.com
45 Artisans Cres	4490 South Hamilton Road	Unit B, Pinnacle 15	Siriusdreef 17-27	DE: de.startech.com
London, Ontario	Groveport, Ohio	Gowerton Rd,	2132 WT Hoofdorp	ES: es.startech.com
NSV 5E9	43125	Brackmills	The Netherlands	NL: nl.startech.com
Canada	U.S.A.	Northampton		IT: it.startech.com
		NN4 7BW		JP: jp.startech.com