

# 7-Port Managed Industrial USB Hub - USB 3.2 Gen 1 5Gbps, ESD Protection

# Product ID 5G7AINDRM-USB-A-HUB Product Diagram (Side A) (Side B)

# **USB Hub Management Software**

To utilize the management features of this USB Hub, it is necessary to download and install the software. To download the USB Hub Management Software, as well as the accompanying documentation, please visit:

www.StarTech.com/5G7AINDRM-USB-A-HUB

# Requirements

- · Host Computer
  - USB-A Port
- 7-24V DC Power Source
- · Flat head Screwdriver
- · (Optional) Phillips head Screwdriver (for DIN Rail Mounting)

For the latest drivers, manuals, product information, technical specifications, and declarations of conformance, please visit: <a href="https://www.StarTech.com/5G7AINDRM-USB-A-HUB">www.StarTech.com/5G7AINDRM-USB-A-HUB</a>

Component		Function
1	USB-A Data Port (Screw Locking)	Connect USB Peripherals
		• USB 3.2 Gen 1 (5Gbps)
		Not Compatible with USB 2.0 (480Mbps)
		Supports up to 5 V/0.9 A (4.5 W) of Power
2	6x USB-A Data/Charge Port (Screw Locking)	Connect USB Peripherals
		• USB 3.2 Gen 1 (5Gbps)
		Backward compatible with USB 2.0 (480Mbps)
		• BC 1.2 for up to 5 V/1.5 A (7.5 W) Charging
3	7x USB Port Status LEDs	Indicates if the Corresponding USB-A Data/Charge     Port is Enabled or Disabled
		Solid Green - USB-A Data/Charge Port Enabled
		Off - USB-A Data/Charge Port Disabled
		Enable/Disable USB-A Data/Charge Ports within the     USB Hub Management Software
4	Mounting Brackets	Mount the USB Hub to a wall or the side/underside of a Desk
5	Power LED	Indicates if the USB Hub is receiving power
		Solid Green - Receiving Power
		Off - Not Receiving Power
6	USB-B Host Port (Screw Locking)	Connect to a USB-A Port on a Host Computer
	(Screw Locking)	• USB 3.2 Gen 1 (5 Gbps)
7	DC 2-Wire Terminal Block Power Input	• Connect a +7~24 V DC Power Source
		90W or Higher Recommended for Maximum     Power Performance
8	DC Power Input (Type-M)	• Connect a +7~24 V DC Power Source
		90W or higher recommended for maximum
		power performance
		Type-M Barrel (5.5 mm Outside Diameter, 2.1 mm Inside Diameter)

# **Package Contents**

• USB Hub x 1

- 6 ft [1.8 m] USB-A to USB-B Cable x 1
- Terminal Block Connector (Attached) x 1
- Quick-Start Guide x 1
- DIN Rail Mounting Bracket (with Mounting Screws) x 2

# Installation

### **Notes:**

- Connect the **Power Source** after all the other installation steps have been completed.
- There are two ways to power the **USB Hub**. Using an external DC Power Adapter or a Terminal Block Power Source. Voltage (+7 - 24 V DC).

### Connect the USB Ports


- 1. Connect up to seven USB peripherals to the USB-A Data/Charge Ports, located on the USB Hub.
- 2. Connect a USB-A Port on the Host Computer to the USB-B Host Port, located on the USB Hub, using the included USB-A to USB-B Cable.
  - The **Computer** will automatically detect the device.

### Power the Hub

### Power the Hub Using the 2-Wire Terminal Block

- 1. Remove the **Terminal Block Connector Housing** from the **USB Hub's Casing**.
- Loosen the screws for the Terminals located on the Terminal Block Connector, using a Flat Head Screwdriver.
- 3. Connect the Positive and Negative Wires from the 7-24V DC Power Source (not included) to the Terminals on the **Terminal Block Connector**.

**Note:** Ensure the polarity of the power input is correctly matched with the **DC 2-Wire Terminal Block Pins** to function properly and to prevent damage to the USB Hub and any connected peripherals.



**Terminal Block Pins** 

### Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols

This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of thirdparty companies not related in any way to StarTech.com. Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by StarTech.com, or an endorsement of the product(s) to which this manual applies by the third-party company in question. StarTech.com hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders.

### Warranty Information

This product is backed by a 2-year warranty.

For further information on product warranty terms and conditions, please refer to www.startech.com/warranty.

### Limitation of Liability

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.

### StarTech.com Ltd.

45 Artisans Cres London, Ontario N5V 5E9 Canada

# StarTech.com LLP

4490 South Hamilton Road Groveport, Ohio 43125 U.S.A. United Kingdom

# StarTech.com Ltd. StarTech.com Ltd.

Unit B, Pinnacle 15 Siriusdreef 17-27 Gowerton Rd, 2132 WT Hoofddorp Brackmills The Netherlands Northampton NN4 7BW

FR: startech.com/fr DE: startech.com/de

ES: startech.com/es NL: startech.com/nl

IT: startech.com/it JP: startech.com/jp 4. Insert the **Terminal Block Connector Housing** back into **USB Hub**.

### Power the Hub Using an External Power Adapter

 Connect a Power Adapter (not included) to the DC Power Input (Type-M), located on the front of the USB Hub and to an AC Electrical Outlet.

# **DIN Rail Mounting**

This **USB Hub** includes **DIN Rail Brackets** that can be used to horizontally mount the **USB Hub** to DIN Rails. To install the **DIN Rail Brackets** on the **USB Hub**:

- 1. Align the **Din Rail Brackets** (x 2) with the DIN Rail Mounting Holes, located on either side at the back of the USB Hub.
- 2. Insert the Mounting Screws (x 4) through the DIN Rail Brackets, and into the USB Hub.
- 3. Using a Phillips Head Screwdriver tighten the **Mounting Screws**. Be careful not to over-tighten the **Mounting Screws**.







# **Regulatory Compliance**

FCC - Part 15

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by StarTech.com could void the user's authority to operate the equipment.

### Industry Canada Statement

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe [B] est conforme à la norme NMB-003 du Canada.

CAN ICES-3 (B)/NMB-3(B)

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.