

ATX Power Supply - 80 Plus® Certified

ATX2PW430WH / ATX2PW500WH / ATX2PW530WH /
ATX2PW550WH / ATX2PW630WH / ATX2PW450BR /
ATX2PW450GO



*ATX2PW430WH shown

FR: Guide de l'utilisateur - fr.startech.com
DE: Bedienungsanleitung - de.startech.com
ES: Guía del usuario - es.startech.com
NL: Gebruiksaanwijzing - nl.startech.com
PT: Guia do usuário - pt.startech.com
IT: Guida per l'uso - it.startech.com
JP: 取扱説明書 - jp.startech.com

For the most up-to-date information, please visit: www.startech.com

FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols

This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of third-party companies not related in any way to StarTech.com. Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by StarTech.com, or an endorsement of the product(s) to which this manual applies by the third-party company in question. Regardless of any direct acknowledgement elsewhere in the body of this document, StarTech.com hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders.



Table of Contents

Introduction	2
Packaging Contents	2
System Requirements.....	2
Installation	2
Hardware Installation	3
Specifications	4
DC Output	7
Connectors for	8
Connectors for	9
Technical Support	10
Warranty Information	10

Introduction

Packaging Contents

- ATX Power Supply
- Quick Install Guide

System Requirements

- ATX compliant motherboard
- ATX compliant computer case that fits a full sized power supply
- Standard Computer Power Cord (Regional AC to C13)

Installation

WARNING! Computer parts can be severely damaged by static electricity. Be sure that you are properly grounded before opening your computer case. StarTech.com recommends that you wear an anti-static strap when installing any computer component. If an anti-static strap is unavailable, discharge yourself of any static electricity build-up by touching a large grounded metal surface (such as the computer case) for several seconds.

Installation of a power supply requires some mechanical skill and requires that you open your computer case to disconnect and reconnect wires. If you are unfamiliar with this kind of work, consider bringing your computer and new StarTech.com power supply to your local computer store for help.

Hardware Installation

1. If replacing an existing power supply, turn your computer off and any peripherals connected to the computer (i.e. printers, external hard drives, etc.).
2. If replacing an existing power supply check to see if it has a power switch on it, set it to the "0" position. Unplug the power cable from the rear of the power supply on the back of the computer and disconnect all other peripheral cables.
3. Remove the cover from the computer case. For detailed steps refer to the documentation included with your computer system, or computer case.
4. If replacing an existing power supply disconnect all of the power connectors from the motherboard and peripheral devices (i.e. hard drives, CD/DVD drives, etc). Make sure to take note of each connector and where they were plugged in. Ensure there are no devices connected to the existing power supply.
5. If replacing an existing power supply remove it from the computer case. This is typically done by removing four (4) mounting screws on the outside face of the power supply. Refer to documentation for your computer system or computer case for specifics.
6. Hold the new power supply into place so that the 4 screw holes around the fan are lined up with installation holes on your computer case, and fix 4 screws (included with your computer case) through the computer case into the power supply. Refer to documentation for your computer system or computer case for specifics.
7. Connect the power connectors from the power supply to the motherboard and any peripheral devices that require power. If you are replacing an existing power supply, replace all power connectors that were removed. Refer to the documentation for your motherboard and peripheral devices for details regarding power requirements.
Note: This power supply uses a 20+4 pin ATX connector, so it can be used on motherboards with either a 20-pin or 24-pin connector. Simply detach the extra 4-pin attachment for use on 20-pin motherboards.
8. Make sure any loose or unused cables from the power supply are away from fans and other moving parts.
9. Place the cover onto the computer case. For detailed steps refer to the documentation included with your computer system, or computer case.
10. Connect the Power Cable
11. Set up your computer system. Refer to documents included with your computer system and any attached devices.
12. The computer system is now ready to be turned on.

Specifications

	ATX2PW430WH	ATX2PW500WH
Standards	ATX12V v2.3 EPS12V v2.92	
Efficiency Rating	80% @ 20% - 86 Watt 80% @ 50% - 215 Watt 80% @ 100% - 430 Watt	80% @ 20% - 110 Watt 80% @ 50% - 275 Watt 80% @ 100% - 550 Watt
Maximum Power Output	430W	500W
Fans	1 x 80mm	
Input Power	100 ~ 240VAC, 10 ~ 5A, 47 ~ 63Hz	
Operating Temperature	0°C to 40°C (32°F to 104°F)	
Storage Temperature	-20°C to 80°C (-4°F to 176°F)	
Humidity	10~90% RH	
MTBF	100,000	
Dimensions (LxWxH)	140mm x 150mm x 86mm	

Specifications cont...

	ATX2PW530WH	ATX2PW550WH
Standards	ATX12V v2.3 EPS12V v2.92	
Efficiency Rating	80% @ 20% - 106 Watt 80% @ 50% - 265 Watt 80% @ 100% - 530 Watt	80% @ 20% - 110 Watt 80% @ 50% - 275 Watt 80% @ 100% - 550 Watt
Maximum Power Output	530W	550W
Fans	1 x 80mm	
Input Power	100 ~ 240VAC, 10 ~ 5A, 47 ~ 63Hz	
Operating Temperature	0°C to 40°C (32°F to 104°F)	
Storage Temperature	-20°C to 80°C (-4°F to 176°F)	
Humidity	10~90% RH	
MTBF	100,000	
Dimensions (LxWxH)	140mm x 150mm x 86mm	

Specifications cont...

	ATX2PW630WH	ATX2PW450BR	ATX2PW450GO
Standards		ATX12V v2.3 EPS12V v2.92	
Efficiency Rating	80% @ 20% - 126 Watt 80% @ 50% - 315 Watt 80% @ 100% - 630 Watt	81% @ 20% - 90 Watt 85% @ 50% - 225 Watt 81% @ 100% - 450 Watt	87% @ 20% - 90 Watt 90% @ 50% - 225 Watt 87% @ 100% - 450 Watt
Maximum Power Output	630W	450W	450W
Fans		1 x 80mm	
Input Power		100 ~ 240VAC, 10 ~ 5A, 47 ~ 63Hz	
Operating Temperature		0°C to 40°C (32°F to 104°F)	
Storage Temperature		-20°C to 80°C (-4°F to 176°F)	
Humidity		10~90% RH	
MTBF		100,000	
Dimensions (LxWxH)		140mm x 150mm x 86mm	

DC Output

ATX2PW450GO

+3.3V	+5V	+12V1	+12V2	+12V3	+12V4	-12V	+5Vsb
20A	20A	37A	37A	37A	37A	0.5A	2.5A

ATX2PW450BR

+3.3V	+5V	+12V1	+12V2	+12V3	+12V4	-12V	+5Vsb
20A	20A	35A	35A	35A	35A	0.5A	2.5A

ATX2PW430W

+3.3V	+5V	+12V1	+12V2	+12V3	+12V4	-12V	+5Vsb
20A	20A	33A	33A	33A	33A	0.5A	2.5A

ATX2PW500W

+3.3V	+5V	+12V1	+12V2	+12V3	+12V4	-12V	+5Vsb
20A	20A	35A	35A	35A	35A	0.5A	2.5A

ATX2PW530W

+3.3V	+5V	+12V1	+12V2	+12V3	+12V4	-12V	+5Vsb
20A	20A	41A	41A	41A	41A	0.5A	2.5A

ATX2PW550W

+3.3V	+5V	+12V1	+12V2	+12V3	+12V4	-12V	+5Vsb
20A	20A	43A	43A	43A	43A	0.5A	2.5A

ATX2PW630W


+3.3V	+5V	+12V1	+12V2	+12V3	+12V4	-12V	+5Vsb
20A	20A	50A	50A	50A	50A	0.5A	2.5A

Connectors for

ATX2PW430WH / ATX2PW500WH / ATX2PW530WH / ATX2PW550WH / ATX2PW450BR
/ ATX2PW450GO




1X ATX 20+4-pin



1 x 4+4 -pin ATX 12V (8-pin
EPS12V)




1 x 6-pin PCI Express




4x 15-pin SATA



3 x 4-pin Molex Power (LP4)



1 x 4-pin




1x 6+2-Pin pin PCI Express

Connectors for

ATX2PW630WH




1X ATX 20+4-pin



1 x 4+4 -pin ATX 12V (8-pin EPS12V)




2 x 6-pin PCI Express



6 x 15-pin SATA



3 x 4-pin Molex Power (LP4)



1 x 4-pin



2x 6+2-Pin pin PCI Express

Technical Support

StarTech.com's lifetime technical support is an integral part of our commitment to provide industry-leading solutions. If you ever need help with your product, visit www.startech.com/support and access our comprehensive selection of online tools, documentation, and downloads.

For the latest drivers/software, please visit www.startech.com/downloads

Warranty Information

This product is backed by a two year warranty.

In addition, StarTech.com warrants its products against defects in materials and workmanship for the periods noted, following the initial date of purchase. During this period, the products may be returned for repair, or replacement with equivalent products at our discretion. The warranty covers parts and labor costs only. StarTech.com does not warrant its products from defects or damages arising from misuse, abuse, alteration, or normal wear and tear.

Limitation of Liability

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.

Hard-to-find made easy. At StarTech.com, that isn't a slogan. It's a promise.

StarTech.com is your one-stop source for every connectivity part you need. From the latest technology to legacy products — and all the parts that bridge the old and new — we can help you find the parts that connect your solutions.

We make it easy to locate the parts, and we quickly deliver them wherever they need to go. Just talk to one of our tech advisors or visit our website. You'll be connected to the products you need in no time.

Visit www.startech.com for complete information on all StarTech.com products and to access exclusive resources and time-saving tools.

StarTech.com is an ISO 9001 Registered manufacturer of connectivity and technology parts. StarTech.com was founded in 1985 and has operations in the United States, Canada, the United Kingdom and Taiwan servicing a worldwide market.